



GENERAL NOTES			CONSTRUCTION STANDARD CITY UTILITIES OF SPRINGFIELD, MISSOURI		
<p>NOTES:</p> <p>1. INSTALL THIS WARNING MARKER ONLY WHERE SPECIFIED ON THE CONSTRUCTION DRAWING. IT IS TO BE USED ONLY ON VALVES WHICH ARE NOT TO BE OPERATED WITHOUT FIRST CONTACTING GAS DISPATCHER PRESSURE CONTROL AND PROPER GAS DEPARTMENT SUPERVISOR.</p> <p>2. USE 3" CAP AND 3" PIPE FOR USE WITH LARGER VALVE BOXES.</p> <p>3. METAL TAG TO READ: "DO NOT OPERATE THIS VALVE WITHOUT FIRST NOTIFYING GAS DEPARTMENT SUPERVISOR".</p> <p>4. WARNING MARKERS SHALL BE INSTALLED ON VALVES THAT ARE NOT TO BE OPERATED, SEPERATE DIFFERENT PRESSURE DISTRICTS, OR VALVES THAT DO NOT FEED ANYTHING BUT STILL NEED TO BE GREASED.</p>			<p>WARNING MARKER FOR VALVE BOX</p>		
LATEST REV. DATE	STANDARD NO.	PAGE:			
05/21/2001	GS-168				