

C.U. GAS MAIN SEGMENT NUMBERING SYSTEM

SIX DIGIT HIGH PRESSURE NUMBERS

SIX DIGIT MAIN SEGMENT NUMBERS ARE ASSIGNED ONLY TO 60 PSIG MAOP MAINS AND HIGHER. THE FIRST NUMBER INDICATES THE OPERATING PRESSURE OF THE MAIN AS FOLLOWS:

- 1 INDICATES 60 PSIG
- 2 INDICATES 60 PSIG
- 3 INDICATES 150 PSIG
- 5 INDICATES 200 PSIG
- 7 INDICATES 350 PSIG
- 9 INDICATES 937 PSIG

THE NEXT TWO NUMBERS COUPLED WITH THE FIRST ONE, INDICATE THE PRESSURE DISTRICT. THE LAST THREE NUMBERS INDICATE THE NUMERICAL ORDER IN WHICH THE NUMBER WAS ASSIGNED.

EXAMPLE: MAIN SEGMENT NUMBER 177298 WOULD INDICATE THE OPERATING PRESURE OF 60 PSIG IN DISTRICT 177 AND THE 298TH NUMBER ASSIGNED IN THAT DISTRICT.

FIVE DIGIT LOW AND INTERMEDIATE PRESSURE NUMBERS

FIVE DIGIT MAIN SEGMENT NUMBERS INDICATE LOW AND INTERMEDIATE PRESSURE NUMBERS. THE FIRST TWO NUMBERS INDICATE THE PRESSURE DISTRICT TO WHICH THE NUMBER IS ASSIGNED. THE LAST THREE NUMBERS INDICATE THE NUMERICAL ORDER IN WHICH THE NUMBER WAS ASSIGNED.

EXAMPLE: MAIN SEGMENT NUMBER 65112 WOULD INDICATE AN INTERMEDIATE PRESSURE MAIN IN DISTRICT 65 AND THE 112TH NUMBER ASSIGNED IN THAT DISTRICT.

△	GENERAL NOTES	CONSTRUCTION STANDARD CITY UTILITIES OF SPRINGFIELD, MISSOURI		
1	MAIN SEGMENT NUMBERS ARE ASSIGNED BY GAS ENGINEERING.	GAS MAIN SEGMENT NUMBER DESCRIPTION		
2	LOW PRESSURE DISTRICTS ARE DISTRICTS 1 – 18, AND DISTRICT 55.			
3	INTERMEDIATE PRESSURE DISTRICTS ARE DISTRICTS 19 – 54, AND 56 – 87.			
		LATEST REV. DATE 1/27/99	STANDARD NO. GS-535	PAGE: