



### MATERIAL LIST

QTY	DESCRIPTION	STOCK NO.	QTY	DESCRIPTION	STOCK NO.
1	1/2 LB DRIVE IN ANODE	202000			

### GENERAL NOTES

- 1 START PILOT HOLE WITH A LONG TAPER PUNCH A MINIMUM OF 6 INCHES FROM RISER. (USE CAUTION NOT TO PERCEIVE SERVICE LINE). USE SAFETY GOGGLES WHEN HAMMERING.
- 2 INSERT ANODE IN PILOT HOLE AND DRIVE TO A MINIMUM OF 3" BELOW GRADE.
- 3 BURY WIRE UNDERGROUND AND WRAP REMAINDER OF WIRE NEATLY AROUND RISER. ATTACH STAINLESS STEEL CLAMP TO RISER WITH SCREW DRIVER AND USE HEXAGON WRENCH FOR SET SCREW ON CLAMP TO MAKE POSITIVE CONTACT TO STEEL GAS RISER.
- 4 AFTER INSTALLATION TAKE PIPE TO SOIL READING ON GAS RISER AND OUTLET PIPING AND ENTER DATA ON THE CORROSION SHEET.
- 5 DO NOT INSTALL ANODES ON ANODELESS RISERS.

CONSTRUCTION STANDARD  
CITY UTILITIES  
OF SPRINGFIELD, MISSOURI

1/2 # ANODE INSTALLATION  
ON STEEL RISER, PLASTIC  
SERVICE WITH LOW P/S  
READING

LATEST REV. DATE 1/8/98 STANDARD NO. GS-430 PAGE: